

01-14-19

Solae locomotive 55 derail damage:

Left Front;

- a) inner and outer truck side frames are bent beyond repair
- b) frame to side frame bolts are sheared
- c) spring saddles and bolts are broken
- d) side bearing bolts are bent
- e) side bearings have some damage

Left 1:

- a) wheel tread is damaged
- b) wheel flange is damaged
- c) inside brake lever is bent
- d) outside brake lever and bolt are broken
- e) brake straps and and bolts are bent and broken
- f) sander hose is broken
- g) gear box is damaged

L 2:

- a) coil spring cradle housing is broken
- b) brake straps and bolts are broken and bent
- c) leaf spring cradle is broken

Right Front:

- a) wheel tread has some damage
- b) wheel flange has some damage
- c) brake cylinder hose is broken
- d) spring cradle bolts are bad order

R1:

- a) sander hose is broken
- b) inside brake lever is bent
- c) brake straps and bolts are bent and broken
- d) brake head bad order
- e) brake guides bent

cont on next page :